


Service Service Service

VCM8935T/00T
VC89355T
VC89755T
98CM355R

NORTH-AMERICAN MODELS:
Service Manual: 8053



Service Manual

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

Contents

Page

| | | |
|-----|----------------------------------|---|
| 1 | Introduction | 2 |
| 2 | Technical Data | 2 |
| 3 | Control Functions | 3 |
| 4. | Connections | 3 |
| 5. | Warnings and notes | 3 |
| 6. | Block Diagram | 3 |
| 7. | Service policy | 4 |
| 8. | Alignment Instructions | 4 |
| 9. | Fault Diagnosis on board level | 5 |
| 10. | Exploded view & Spare parts list | 5 |
| 11. | Complaint description form(s) | 6 |

1. Introduction

X9-B/W (Eco) is a new family of CCD Black & White Observation Cameras.

This family covers following type of cameras:

| | |
|-------------|---------------------------|
| VCM8935/00T | 4 mm F1.2 integrated lens |
| VC89355T | 4 mm F1.2 integrated lens |
| VC89755T | 4 mm CS-lens |
| 98MC355R | 4 mm F1.2 integrated lens |

This range of camera packs is the fully backwards compatible successor of the X1- B/W (VCM81..) range of camera packs.

2. Technical Data

| | |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Power supply voltage | 9.6 to 27V DC , as supplied by observation system monitor or the system junction box, connected with max. 200 m. recommended cable. |
| Power consumption | 50 mA at 24V DC |
| Power source | Any DC voltage generator (including observation system monitor), feeding through the signal coax cable. The DC voltage plus ripple must remain within the limits of 9.6 - 27V DC at the camera entrance. |
| System cable | 4-wire twisted pair of telephone cable (25 m included in the carton). |
| Video output | 2-wire interface via system cable. |
| Sound output | 2-wire interface via system cable. TV system dependent. |
| Microphone | Built in, electret (can be switched-off on the camera). |
| Synchronization | None |
| Pick up element | 1/3" Solid state CCD EIA : LZ2336 PAL : LZ2346 |
| Picture elements | 362(H) x 492(V) for EIA 362(H) x 582(V) for PAL |
| Gamma | fixed 0.45 |
| Gain control | Automatic -6 to 18 dB. |
| Sensor illumination range: | |
| . for integrated lens: | 2.5 lux (50 IRE) to 30000 Lux F2.0, 3200K, lens transmission 80%, scene reflection 75% |
| . for CS mount lens: | 1 lux (50 IRE) to 11000 lux F1.2, 3200K, lens transmission 80%, scene reflection 75% |


2. Technical Data

X9 - B/W


3

| Lens | Integrated Lens | CS-mount |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|
| Mounting | fixed mount | CS standard |
| Image format | 1/3" | 1/3" |
| Focal length | 3.8 mm | 4 or 8 mm |
| Angles of view | 64.4 deg. horizontal 49.6 deg. vertical | 61 or .. deg. horizontal 48 or .. deg. horizontal |
| Relative aperture | F2.0 | F1.2 |
| Focus | fixed, 1m - infinity | adjustable |
| Dimensions (HxWxD) | 70 * 70 * 54 | 70 * 70 * 79 (with lens) |
| Weight | 130 g. | 205 g. (with lens) |
| Ambient temperature | | |
| Operating | -20° to +55° Centigrade. | |
| Storage | -25° to +70° Centigrade. | |
| Ambient humidity | | |
| Operating | 20 to 90 % RH | |
| Storage | up to 99 % RH | |
| Service policy | First line service: Board swapping using simple diagnoses, see chapter 9 for the details. Second line service: Central repair at factory, see chapter 7 for the details. | |

3. Control Functions




1. Sound on/off switch




2. Focus ring
3. Objective
4. CS-casing
5. Blocking ring

4. Connections





1. System cable



1. System cable
2. Diaphragm cable

5. Warning and Notes


WARNINGS

1. NEVER measure directly at the output of the CCD image sensor.
It will destroy the sensor immediately.
2. Safety regulations require that the unit should be returned in its original conditions and that components identical to the original components are used. The safety components are indicated by the symbol .
3. All ICs and many other semi-conductors are sensitive to electrostatic discharges (ESD) .
Careless handling during repair can drastically shorten the life. Make sure that during repair you are connected by a pulse band with resistance to the same potential as the earth of the unit.
Keep components and tools also at this same potential.
4. When making settings, use plastic rather than metal tools. This will prevent any short-circuit and the danger of a circuit becomes unstable.
5. Always switch off the set before replacing any of the components or separating the PW boards.
6. Never aim the camera at the sun or other extremely bright light sources.

NOTES:

1. This manual is prepared for all types of cameras (known at this moment) within X9- B/W (Eco) family range.
The types are mentioned on the front page as well as in the Introduction chapter.
This manual support the board swapping repairs.

6. Block Diagram



7. Service policy

X9 - B/W

4

The Service policy for this product is : board swapping as first line service. It means only replacement of the defective board. In case of necessary repairs, the defective "repairable" boards must be returned to Philips Consumer Service according the central repair procedure.

This camera type contains one assembly, which can be repaired centrally via the so called "central repair procedure".

The relevant panels are mentioned under the heading "Repairables" in chapter 10 (spare parts list).

The central repair procedure has been introduced to guarantee a fast, efficient and correct repair of panels or assemblies with complex circuitries or new technologies.

Central Repair Procedure:

Contact your local service organisation to obtain a repairable board. After confirmation a replacement panel or assembly will be sent to you. Send the defective panel or assembly inclusive a "(standard) repair form" to your local service organisation.

The defective panel should be correctly packed inclusive ESD protecting material. The original packing of the returned/replacement panel can be used for this purpose. The accompanying "repair form" of chapter 11 should contain all basic information such as:

- full model number of the set
- date of failure
- reporting country
- serial number/production code of the set
- description of the failure including timing indication (immediate, after ... minutes warming up, sometimes)

8. Alignment Instructions

Aligned boards will be offered as spare parts.


You, therefore, do not need any such alignments. However, as a precaution we are also including these alignment instruction as follows:

Used measurement equipment:

- dual trace oscilloscope (30MHz) PM3262
- triple power supply PE1542
- automatic multimeter PM2519
- frequency counter PM6673
- monitor for CCIR/EIA
- Test Box:
 - Dai Nippon light box (4x FL-10W)
 - Luminance 850 NT +/- 50 NT
- DNP EIAJ test chart-A (resolution chart)
- DNP EIAJ test chart-J (V/10 chart)
- DNP EIAJ test chart-II (11 steps Y= 0.45, grey scale)
- N.D. filter 2.0 and 3.0

Connection sensor panel:

Connect the voltages (+13.2V, +5V) to the sensor panel. Connect a 75Ω video buffer to the video-output of processing IC 7180 (T202) acc. to figure 1.



Terminate the videosignal at the monitor with 75Ω .
Connect the videosignal also to the oscilloscope and trigger on it. Settings oscilloscope 200mV/div and $20\mu\text{s}/\text{div}$.

Keep this signal during adjusting connected to the oscilloscope and connect the probe for measurements to the other channel.

Switch on the power-supply and measure the current:

| | |
|--------------------------------------|-------------------------------------------|
| pin 4 connector 1900 13.2V | : 8 mA |
| pin 8 connector 1900 5V | : 75 mA |
| Measure the oscillator freq. on T175 | : $6.75 \text{ Mhz} \pm 27 \text{ kHz}$. |
| Measure the Max.gain on T231 | : $\leq 2.35\text{V}$ |
| Measure the Gamma on T251 | : $1.4 \pm 0.15 \text{ V.}$ |
| Measure the Knee on T253 | : $3.4 \pm 0.15 \text{ V.}$ |
| Measure the Apa-ctrl T223 | : $2.4 \pm 0.15 \text{ V.}$ |
| Measure the Bclip on T220 | : $1.5 \pm 0.15 \text{ V.}$ |
| Measure the Gain-ctrl on T216 | : $3.4 \pm 0.10 \text{ V.}$ |
| Measure the Wclip on T209 | : $2.8 \pm 0.10 \text{ V.}$ |
| Measure the Pedestal on T205 | : $2.7 \pm 0.15 \text{ V.}$ |
| Measure the Setnr on T184 | : $2.6 \pm 0.10 \text{ V.}$ |
| Measure the Setnr on T185 | : $2.4 \pm 0.10 \text{ V.}$ |

Adjustment of the back focus:

Aim the camera (sensor panel) to a resolution testchart approximately 2.5 meters in front of the lens.

Adjust the back focus of the lens, so that the visible moire in the video image has reached its maximum intensity.

Adjustment anti-blooming (ofd):

Aim the camera to a V/10 chart. The square should be in the middle of the image.

Adjust 3142 (OFG) so that no blooming occurs.

Check shutterspeed:

Point camera to the Dai Nippon lightbox. Place a grey scale chart in the light box. Connect an oscilloscope to T230, pin 43 of IC 7180. Settings oscilloscope: 100mV/div and $20\mu\text{s}/\text{div}$. Hold your hand before the camera lens for a moment so you can determine the black level of CDS output signal. Check the amplitude of video signal; the level is 200mVpp. Change scene illumination from low light to high light and see whether the monitor video signal level on oscilloscope doesn't change in amplitude.

Adjustment agc:

Point camera to a grey scale chart. Connect oscilloscope to video output.

Settings oscilloscope 200mV/div and $20\mu\text{s}/\text{div}$. Adjust 3249 (AGC) so that output level is 1Vpp. Place ND filter 3.0 in front of the lens and see whether AGC is working.

Check anti-blooming level:

Point camera to a V/10 chart. The square should be on top of image. Place a ND-filter in front of the lens with value of 2.0.

Connect an oscilloscope to testpoint T230. Settings: 50mV/div and $20\mu\text{s}/\text{div}$.

Adjust the light intensity so that the CCD sensor signal level is 200mV at the square.

Remove the ND-filter and check for Anti-blooming (this effect is best seen in differences in smearing). If necessary then re-adjust 3142 (OFG). Then point camera to an equally white scene and check on monitor whether Light Fixed Pattern Noise is visible, if so then re-adjust 3142 (OFG) lower.

9. Fault Diagnosis on Board level

X9 - B/W

5

Before starting with the diagnosis, connect the "defective" camera according Fig. 9.1 to a test monitor.

Note: This circuit is advised for checkin purpose. The pin numbers (2 to 5) of the camera cable are the same as pin numbers of the connector 1902 on the power board of the camera.





Fig. 9.1


- A- Check if the audio switch of the camera is in the position "ON"
- B- Measure the voltage between pins 4 and 5 of the cable. It should be 23 Volt \pm 2 V.
- C- Replace the test monitor by another one.
- D- Measure the voltages between pins 2 and 5 and between pins 3 and 5 of the cable. They should be 6,3 Volt \pm 0,5 V
- E- Open the camera housing.
- F- Measure the voltages on pin 4 and 5 of the AMP connector 1900 on Power board. It should be 13,2 Volt \pm 0,3 V.
- G- Measure the voltages on pin 8 of the AMP connector 1900 on Power board. It should be 5 Volt \pm 0,1 V.
- H- Replace Sensor Board
- I- Replace Power Supply Board

Symptom: No Picture or Poor Picture
No audio or poor audio



CL 46620019/014
300894

10. Spare Parts Lists



| POSITION NUMBER | SERVICE CODE | DESCRIPTION |
|----------------------------------------------------------------------------|----------------|---------------------------------------------|
| 1 | 4822 432 60924 | Rear cabinet- grey |
| 1 | 4822 432 60928 | Rear cabinet- black |
| 2 | 4822 466 93052 | Spacer (2*) |
| 3 | 4822 532 61221 | Sensor interface |
| 4 | 4822 532 12133 | CS-mount ring |
| 5 | 4822 432 60925 | Front cabinet- grey |
| 5 | 4822 432 60926 | Front cabinet for CS-mount |
| 5 | 4822 432 60927 | Front cabinet- black |
| 6 | 4822 532 12134 | Retaining ring |
| 7 | 4822 381 11473 | CS-lens 4 mm F1.2 |
| 8 | 4822 256 80074 | Lens holder |
| 9 | 4822 381 11472 | Lens 3.8 mm F2.0 |
| 10 | 4822 462 10507 | Tripod assy- grey |
| 10 | 4822 462 10516 | Tripod assy- black |
| 11 | 4822 413 41884 | Knob for tripod- grey |
| 11 | 4822 413 41885 | Knob for tripod- black |
| 12 | 4822 505 10665 | Lock nut M5 for tripod |
| 13 | 4822 502 21582 | Screw M5*8 for tripod |
| 50 | 4822 502 13887 | Torx screw 2*20 (4*) |
| 51 | 4822 502 13886 | Torx screw 2*5 (2*) |
| 52 | 4822 505 10635 | Lock nut M3 |
| 53 | 4822 502 10176 | Screw M3x5 |
| Various: | | |
| | 4822 321 62696 | Camera cable 15 meter |
| Electrical: | | |
| 1021 | 4822 212 31668 | power supply pwb assy |
| 1100 | 5322 265 40903 | 10 pins female connector on sensor board |
| 1265 | 4822 242 30176 | Microphone |
| 1870 | 4822 277 21765 | Switch (AUDIO OFF/ON) |
| 1900 | 4822 265 41281 | 10 pins female connector on power board |
| 1902 | 4822 267 41183 | 4 pins (telephone) connector on power board |
| REPAIRABLES: | | |
| These unit can be returned to PCS for repairing at factory, see chapter 7. | | |
| 1020 | 4822 212 31674 | Sensor pwb assy (VCM8935/..T) |
| 1020 | 4822 212 31307 | Sensor pwb assy (VC89355T, 98MC355R) |
| 1020 | 4822 212 31673 | Sensor pwb assy (VC89755T) |

11. Complaint description form(s)

X9 - B/W

6



FAULT DESCRIPTION FORM

Model number of the defective product :

Date of failure: .. - .. - 19..

Serial number of the defective product : OP.... 9.....

Country :

Fault description :

Please add this description form in the box with the defective panel !!



FAULT DESCRIPTION FORM

Model number of the defective product :

Date of failure: .. - .. - 19..

Serial number of the defective product : OP.... 9.....

Country :

Fault description :

Please add this description form in the box with the defective panel !!



FAULT DESCRIPTION FORM

Model number of the defective product :

Date of failure: .. - .. - 19..

Serial number of the defective product : OP.... 9.....

Country :

Fault description :

Please add this description form in the box with the defective panel !!



FAULT DESCRIPTION FORM

Model number of the defective product :

Date of failure: .. - .. - 19..

Serial number of the defective product : OP.... 9.....

Country :

Fault description :

Please add this description form in the box with the defective panel !!